


INSTRUCTION BOOK
and
OPERATING MANUAL

Amateur Trans-citer

MODEL AF.68



**MULTI-
ELMAC**

MULTI-PRODUCTS COMPANY
OAK PARK 37, MICHIGAN

SAFETY NOTICE

Equipment is so designed that when all covers are in place there is no shock hazard. Do not leave the equipment unattended with any of the covers removed.

Maintenance and operating personnel must at all times observe all safety precautions. Under certain conditions, dangerous voltages may exist with the power turned off, due to capacitors retaining a charge. To avoid casualties, always remove the power and discharge or ground all circuits prior to touching them or removing components.

Maintenance personnel should familiarize themselves with the technique of resuscitation found in any First Aid manual.

Amateur Trans-citer

MODEL AF-68



MULTI-PRODUCTS COMPANY

Manufacturer of

MULTI-ELMAC

**RADIO COMMUNICATIONS
AND CONTROL EQUIPMENT**



21470 COOLIDGE HIGHWAY

OAK PARK 37, MICH.

Form No. M-158

Instruction Manual

FOR

MULTI-ELMAC TRANS-CITER—MODEL AF-48

SECTION 1 — Description

1.1	General	2
1.2	Excise Class Operation	2
1.3	Technician Class Operation	2
1.4	Diagrams	2
1.5	Circuit Description	2
1.6	Frequency Coverage	2
1.7	Tube Complement	4
1.8	Output	4
1.9	Audio	4
1.10	Power Supply	4
1.11	Power Connector	4
1.12	Accessories	4

SECTION 2 — Installation and Operation

2.1	General Considerations	5
2.2	Mounting Methods	5
2.3	Antenna	5
2.4	T. V. L. Precautions	5
2.5	Power Supply Requirements	5
2.6	Controls	6
2.7	Power Supply Connections	6
2.8	Booster	6

SECTION 3 — Service and Alignment

3.1	General	7
3.2	Tubes	7
3.3	Circuit Failures	8
3.4	General Alignment Instructions	8
3.5	F.F.O. Alignment	8
3.6	Buffer-Driver Alignment	8
3.7	Crystal Controlled Operation	14

SECTION 4 — Appendix

4.1	Parts List	11
4.2	Resistor Graph	14
4.3	Operating Voltage Chart	15
4.4	Control Layout	Drawing No. 894
4.5	Chassis Layout	Drawing No. 895
4.6	Typical Power Plug Connections	Drawing No. 219
4.6a	Power Connections M1030 Bagby	Drawing No. 513
4.7	Schematic Wiring Diagram	Drawing No. 894

SECTION I

Description

- 1.1 GENERAL.** The MULTI-BAND AF-68 Trans-citer is a 8 tube variable frequency or crystal controlled 40 Watt transmitter or exciter. All circuits are simultaneously switched to the desired band by a single bandswitch control.

Designed as a complete transmitter for mobile or fixed installations, or an exciter to drive a higher power transmitter. When used as an exciter the 500 ohm tap on modulation transformer can be used to drive the higher power modulator.

- 1.2 NOVICE CLASS OPERATION.** The AF-68 Trans-citer is ideally suited for novice operation. With the two (2) crystal positions, crystal controlled operation is afforded and the power capabilities are within the legal limits required by novice regulations. Provision for CW keying is included.

- 1.3 TECHNICIAN CLASS OPERATION.** With the inclusion of the 5 meter band, a highly stable VFO and full carrier amplitude modulation, the AF-68 is ideally suited for the Technician.

- 1.4 DIMENSIONS.** The maximum external dimensions of the AF-68 Trans-citer, excluding projections of control knobs, is 13-1/2 inches wide, 6-1/2 inches high, and 3-1/2 inches deep behind panel. Approximate weight is 17 pounds.

- 1.5 CIRCUIT DESCRIPTION.** The AF-68 Trans-citer employs a variable frequency oscillator with output on either 3.5 to 4 Mc., 7 to 7.5 Mc. or 13.5 to 13.8 Mc. In addition to the VFO bands, two crystal positions are included for operation on two spot frequencies. Any crystal that will work straight through, double, triple or quadruple to the desired frequency may be used. The oscillator circuit employs a voltage regulator tube to maintain the plate voltage at a constant level.

The multiplier stages are broad band with a front panel control for peaking the final grid, insuring best performance on all bands. The audio circuit is designed to use either a carbon microphone or a low output microphone such as a crystal or dynamic. A slide switch on the AF-68 Trans-citer sets up the circuit for use with either type of microphone. The variable frequency oscillator dial and the meter scale is illuminated. The variable frequency oscillator dial scale is directly calibrated in megacycles for each of the amateur bands.

1.4 FREQUENCY COVERAGE

80 Meter Band	3.5 to 4	mc.
40 Meter Band	7 to 7.5	mc.
20 Meter Band	14 to 14.35	mc.
15 Meter Band	18 to 18.45	mc.
10 Meter Band	28 to 29.7	mc.
6 Meter Band	50 to 54	mc.

American phone band segments are marked by a solid line on the VFO dial.

1.7 TUBE COMPLEMENT. The AP-68 Transmitter is supplied complete with all tubes, listed in the individual unit, as follows:

6AK5	Oscillator
6AQ5	Buffer-amplifier
6AQ5	R.F. Driver
6X4B	Final R.F. Amplifier
6AD6	Speech amplifier
11A01	A.F. Driver
6L6GB (2)	D.F. Modulators
#44 (2)	Diode tubes
#04	Meter pilot light

1.8 OUTPUT. The AP-68 Transmitter is designed for use with a resonant antenna coupled to its output with a transmission line of 50 to 100 ohm impedance. Other impedances or balanced lines can be coupled through the use of an antenna tuning device. When used as an exciter the coupling link of the high powered final can be directly connected to the AP-68 with a suitable length of coaxial cable. The MULTI-ELMIAC AP-68 is designed for a maximum plate power input of 60 (about) watts. Maximum ratings for this Transmitter are 600 volts at 100 milliamperes, or 500 volts at 120 milliamperes. Full 100% modulation occurs when the modulator plate current ratings is about 60% of the final plate current with normal voice frequencies.

1.9 AUDIO. The modulation transformer is provided with a 500 ohm output tap brought to the power plug for driving the grids of high powered modulators. The 6L6GB's will deliver approximately 35 watts of audio with a plate supply of 500 volts.

1.10 POWER SUPPLY. The AP-68 Transmitter was intentionally designed to use an external power supply in order to permit: (a) use of PMP-T receiver power supply to supply the low level stages, (b) use of the AP-68 Transmitter with an AC operated power supply at a fixed or portable location, (c) use of a dynamotor or vibrator supply in mobile installations, or (d) use of the Transmitter as a detector/amplifier for high powered transmitters. A variable MULTI-ELMIAC power supply MODEL PS-2V or M1070, M1071 for portable or fixed station operation from 115 volt AC lines is available.

1.11 POWER CONNECTOR. A 15 prong female connector is provided with each unit. The 15 prong connector allows all circuits to be arranged for maximum flexibility, making it possible to use the AP-68 Transmitter in various types of installations.

1.12 ACCESSORIES. The following accessories are available for use with the AP-68 Transmitter:

PS-2V--A universal 115 volt AC supply. (Supplies 5 or 12 volts for filaments and two separate high voltages.)

M1070--A universal 5 or 12 volt DC and 115 volt AC power supply. (Supplies filament voltage, one low voltage regulated source and two separate high voltages.)

M1071--Same as M1070 but sold in kit form.

CPS-1--Cable with a 15 prong female connector and bonding strip to connect the AP-68 to the PS-2V power supply.

NOTE: Due to different requirements, for individual installations, no cable for the M1070 (or M1071) power supply is available from the factory.

SECTION 2

Installation and Operation

2.1 GENERAL CONSIDERATIONS. No two installations being similar, the individual owner of the AF-68 Trans-citer will vary his installation according to space and operating practices. Regardless of these variations whenever the Trans-citer is installed in a mobile unit, there are two essentials that must be observed for proper installation: (1) convenient location for operation, including ease of observation; (2) rigid mechanical mounting. The owner desiring to use the AF-68 as an exciter for higher powered equipment will have his own methods, etc. The usual standard practices for fixed or portable installations will suffice.

2.2 MOUNTING METHODS. The construction of the cabinet of the AF-68 Trans-citer is such that it is readily adaptable to hanging mount from the lower edge of the car dash board or a fixed bottom bracket to the floor of the car. A brace in the fire wall will help make a more rigid installation. The AF-68 cabinet is equipped with felt feet for desktop mounting in fixed or portable installations.

2.3 ANTENNA. The MULTIELMAC AF-68 Trans-citer will perform most efficiently when coupled to an antenna resonant to the desired operating frequency. Standard practices should be used for antenna relay control. Typical mobile circuits are shown on drawing #219, page 31, of this manual. The coaxial output connector serves as an output terminal for the transmission line. Coaxial connectors allow the installation of low-pass filters between the Trans-citer and the antenna or antenna tuners. The type of antenna depends upon the individual's preference. The following types of antennas can be directly fed from the AF-68 without an antenna tuner:

- Center fed half-wave dipole
- Folded half-wave dipole
- Parabolic beams
- Vertical quarter-wave ground plane
- Base or center-loaded mobile whips
- Vertical half-wave dipoles, center fed
- Any antenna fed with low impedance balanced line.

Refer to the various handbooks on operating other types of antennas such as long wires, top loaded, off center fed, loop H, sterco curtains, phased arrays and the like.

2.4 T.V. PRECAUTIONS. The MULTIELMAC Trans-citer's circuitry is such that harmonic falling in the TV channels are at a minimum. The power plug leads are bypassed and other critical circuits designed for maximum harmonic attenuation. Under normal operating conditions the usual low-pass filter in the antenna transmission line, a brace-brace filter in the AC power line, and a good efficient ground to the Trans-citer cabinet is sufficient to maintain a harmonic attenuation of 100 db down. Adequate shielding of stages and a completely shielded variable-frequency oscillator makes this possible.

2.5 POWER SUPPLY REQUIREMENTS. For maximum flexibility the AF-68 Trans-citer power input is arranged for one or two* separate high voltage supplies. Filament input is arranged for either 6 volts @ 5.2 amp. or 12 volts @ 2.5 amp. AC or DC. (Refer to Drawing #219, page 31, for proper connections.) Plate supply required: 500 volts max. @ 100 ma. and 250 volts max. @ 75 ma.

*Any single high voltage supply may be used with a dropping resistor as determined from the graph on page 14 of this manual. Any supply delivering 100 to 500 volts @ 215 ma. plus the proper filament voltage will suffice.

For mobile operation the power supply of the PMP-1 receiver may be used for the 250 volt supply and the small dynamotor for the higher voltage supply. By using the receiver power supply for the low level stages the drain on the dynamotor is minimized resulting in more efficient dynamotor operation. More high voltage at a lower battery drain will be realized. Refer to drawing #219, page III, for typical circuits.

2.6 CONTROLS. Sufficient controls have been incorporated for maximum flexibility, at the same time keeping operation simple. (See drawing #894, page 17.)

- Bandswitch Switches all circuits to the desired amateur band simultaneously.
- Meter switch A 5 position meter function switch.
1. Final grid current, Final off.
 2. Final grid current, Final on.
 3. Final plate voltage, Final on.
 4. Not used, Final on.
 5. Modulator plate current, Final on.
 6. Final plate current, Final on.
- Load control Controls final load in antenna.
- Plate tuning Extends final tank circuit.
- Grid tuning Tunes final grid.
- Power "on-off" switch . . . Turns filament on or off in a mobile installation, also controls primary power in an AC installation.
- VFO switch Connects VFO to receiver power supply for stereo hearing a carrier.
- Mike jack Microphone and push-to-talk circuit connections.
- Key jack Key connections for CW operation.
- Crystal socket Will hold two crystals in PT 243 holders (located behind the meter).
- VFO-Crystal switch Selects either variable frequency operation or operation from either of the two crystals inserted in the socket above.
- VFO control Variable frequency oscillator frequency control, reads directly in megacycles.
- A.F. Gain control Controls percentage of modulation.
- AM-CW switch Selects either amplitude modulation or A1 emission.
- ED-2 or Carbon slide switch (On left side of chassis below meter.) High position for crystal or dynamic microphones, low for carbon microphones.

2.7 POWER SUPPLY CONNECTIONS. A 15 prong plug is used for all connections and various possible combinations are diagrammed in drawing #C18.

2.8 EXCITER. Drawing below shows a method of using the AP-48 Transmitter as an A.F. and R.F. driver to excite a high power amplifier and modulator. For power plug connections see drawing No. 218, figure 5.

ANY FINAL, REQUIRE UP TO
50 WATTS RF DRIVE.

SEE MODULATOR REQUIRE UP TO
50 WATTS RF DRIVE.



AP-48 USED AS RF EXCITER AND SPEECH AMPLIFIER-DRIVER

SECTION 3

Service and Alignment

3.1 GENERAL. Satisfactory operation of this Trans-citer depends on several factors. Before removing a transmitter which is performing in an unsatisfactory manner, carefully inspect antenna connection, power cables and plugs, the storage battery and its connections (if a vehicular installation), the AC power source (if operated at a fixed location), and the microphone and relay connections. It is an aggravating waste of time and effort to remove and attempt to service a transmitter when the trouble is an external one.

- (a) **ANTENNA.** If the Trans-citer is functioning properly but does not load, look for a broken antenna lead, bad relay contacts or inoperative relay, shorted transmission line or antenna insulator.
- (b) **LOADING.** If a dip in the plate current meter cannot be obtained after several rotations of the plate tuning condenser, with the load control set near minimum, turn the transmitter off and check for an improper output lead as outlined under *Antenna*.
- (c) **STORAGE BATTERY.** Check periodically the terminal voltage, specific gravity, level of electrolyte, and the tightness of connections. Check the battery voltage at the Trans-citer power plug with the Trans-citer operating and drawing full load.
- (d) **CABLES AND PLUGS.** The initial installation should locate all cables and plugs where they will not be exposed to physical shock or subjected to belaying and kinking.
- (e) **TRANSMITTER TESTING.** A quick method for checking the transmitter performance is to substitute a 50 watt lamp for the antenna. After the lamp has been connected to the transmitter, either direct or thru the relay, adjust the loading and final controls until the lamp is two thirds normal brilliance. With the audio gain control set normally the bulb should double in brilliance on modulation peaks.

If the lamp loads the transmitter, as outlined above, but the antenna will not load the transmitter it indicates the antenna is not resonant to the frequency of operation or the feedline impedance is incorrect.

NOTE: Never load the AF-48 Trans-citer beyond the point where a dip is no longer indicated by resonance in the final plate current meter. When loading to maximum, adjust the loading control so that approximately a 10% dip can be obtained when the final tuning condenser is rotated through resonance with the load connected.

3.2 TUBES. Even though modern methods produce more reliable tubes than ever, the first source of trouble is likely to be a defective tube. Tube failure will produce low grid drive, low plate current, intermittent operation, or a completely dead transmitter. Where a tube change is made in the R.F. portion of the Trans-citer it should be replaced with the same make of tube. If this is not possible the circuits may have to be realigned according to paragraphs 3.3 and 3.6 of this section.

3.3 CIRCUIT FAILURES. Excluding tubes, the most common source of circuit failure, will invariably be found in the many resistors and capacitors within the Transmitter. A defective resistor or condenser can usually be found by a point-to-point continuity test, although a careful visual inspection will often show the defective part, such as a charred resistor. The operating voltage chart on page 15 permits a careful check of operating elements. All measurements are taken with the final plate GPP, bandswitch in the 30 meter position, VFO set to 3.5 megacycles, final grid current regulated for maximum grid current, crystal-VFO switch in VFO position, and audio gain control at minimum. A 30,000 ohms per volt meter is used. (DO NOT use a vacuum tube voltmeter since it will read erroneously in an H.F. field.) These measurements were taken using a 250-0V or the M1078 power supply and a line voltage of 117 volts A.C. Any power supply can be used that will give the same high voltage.

3.4 GENERAL ALIGNMENT INSTRUCTIONS. Thoroughly familiarize yourself with the layout of all coils and tuning adjustments as shown on drawing #685, page 16, before beginning an alignment. Check all brass slug adjusting screws to make sure that they are not worn so much that they will not hold their setting. If they are too worn to be serviceable they must be replaced.

Check the pointer to see that it is aligned properly with respect to the steps on the VFO dial.

You will need an accurate receiver and an accurate signal generator and/or crystals to spot the nonlinear band edges.

An alignment job can never be any better than the equipment with which the Transmitter was aligned.

3.5 VARIABLE FREQUENCY OSCILLATOR ALIGNMENT.

NOTE: Before the oscillator section is aligned the cover plate must be in position and the retaining screws inserted and tightened.

Turn the meter switch to the left "0" position. Final off.

Set bandswitch to the 40 meter position.

Set VFO-crystal switch to the VFO position.

Set the VFO dial to 3.5 megacycles.

Set signal generator at 3.5 megacycles, tune receiver to 3.5 megacycles.

Apply plate power to VFO.

Adjust screw #1 until a beat is obtained at 3.5 Mc.

Set the VFO dial to 4.0 megacycles.

Set signal generator and receiver to 4.0 megacycles.

Adjust trimmer #2 for a beat at 4.0 megacycles.

Readjust at 3.5 megacycles, then again at 4.0 megacycles.

It may take several excursions between 3.5 and 4.0 megacycles before a good alignment is achieved.

Set the bandswitch to the 15 meter position.

Set the VFO dial to 20 megacycles.

Set the signal generator and receiver to 20 megacycles.

Adjust screw #3 until a beat is obtained at 20 megacycles.

The remainder of the 15 meter band should be correct.

Set the bandswitch to the 18 meter band.
Set the VFO dial to 21.45 megacycles.
Set the signal generator and receiver to 21.45 megacycles.
Adjust trimmer #4 for a beat at 21.45 megacycles.
The remainder of the 18 meter band should be correct.

The 40 and 30 meter bands will be correct after the 18 meter band is aligned.

Set the bandswitch to the 6 meter band.
Set the VFO dial to 51 megacycles.
Set the signal generator and receiver to 51 megacycles.
Adjust screw #5 for a beat at 51 megacycles.
The remainder of the 6 meter band should be correct.

3.6 BUFFER-DRIVER ALIGNMENT.

Alignment must be followed in the sequence as outlined below.

NOTE: Before aligning the buffer-driver section a bare metal plate should be inserted under the open side of the chassis. This will give the same effective capacity and shielding as the cabinet.

Set the bandswitch to the 18 meter position.
Set the VFO dial to 18.5 megacycles.
Set the final grid tuning condenser at about the half capacity position.
Adjust screws #6 and #7 for maximum grid drive as shown on the meter.

Set the bandswitch to the 18 meter position.
Set the VFO dial to 20.7 megacycles.
Set the final grid tuning condenser at about the half capacity position.
Adjust screws #8 and #9 for maximum grid drive as shown on the meter.

Set the bandswitch to the 20 meter position.
Set the VFO dial to 14.2 megacycles.
Set the final grid tuning condenser at about the half capacity position.
Adjust screw #10 for maximum grid drive as shown on the meter.

Set the bandswitch to the 40 meter position.
Set the VFO dial to 7.2 megacycles.
Set the final grid tuning condenser at about the half capacity position.
Adjust screw #11 for maximum grid drive shown on the meter.

Set the bandswitch to the 80 meter position.
Set the VFO dial to 3.75 megacycles.
Set the final grid tuning condenser at about the half capacity position.
Adjust screw #12 for maximum grid drive shown on the meter.

Set the bandswitch to the 6 meter position.
Set the VFO dial to 51 megacycles.
Set the final grid tuning condenser at about the half capacity position.
Adjust screws #13 and #14 for maximum grid drive on the meter (adjustments #13 and #14 should peak with the screws extending about 1/2").

NOTE: When tuning the buffer and driver stage it is well to use a grid dip meter or wave meter to make sure all the coils are tuned to the proper bands or harmonics.

Alternate method of aligning the 6 meter buffer-doubler.

Set the bandswitch to the 6 meter position.

Set the VFO dial to 31 megacycles.

Rotate the final grid tuning condenser for maximum grid drive on the meter. (Maximum drive should occur about mid-position of the final grid tuning condenser. If not, check L26 the air kern four (4) turn coil mounted under the chassis near the band switch. Spacing between turns should be approximately 3/16 inch.)

Alternately rotate the final grid tuning condenser and adjust screws #13 and #14 for maximum output as indicated on the meter. (Screws #13 and #14 should peak when extending about 1/2 inch.)

3.7 CRYSTAL CONTROLLED OPERATION. When operating in the crystal controlled position the doubling, tripling or quadrupling is accomplished in the plate circuits of the 8AQ5 and 8AQ5 stages. The following chart gives the recommended crystal frequencies for operation within each of the six (6) amateur bands covered by the AF-48 Trans-citer.

Band

80	1.75 to 2	mc.	or	3.5 to 4	mc.
40	3.5 to 3.85	mc.	or	7 to 7.5	mc.
20	5.5 to 5.97	mc.	or	1 to 1.175	mc.
15	7 to 7.15	mc.			
10	7 to 7.425	mc.			
5	*12.5 to 13.5	mc.	or	3.5 to 4	mc.

NOTE: *12.5 to 13.5 mc. crystals are recommended for 5 meter crystal controlled operation.

NOTE: It is a good policy not to operate too close to the band edges. Since some crystals do deviate slightly from the marked frequency it is wise to choose a crystal within 2 or 3 kilocycles of the band edge.

SECTION 4

Appendix

4.1 PARTS LIST

R11	47K	ohms	1 watt	10%
R12	47K	ohms	1 watt	10%
R13	1000	ohms	1 watt	10%
R14	33K	ohms	1 watt	10%
R21	33K	ohms	1 watt	10%
R22	100	ohms	1 watt	10%
R23	47K	ohms	1 watt	10%
R24	680	ohms	1/2 watt	10%
R25	270	ohms	1/2 watt	10%
R26	68	ohms	1/2 watt	10%
R27	180	ohms	1 watt	10%
R31	100K	ohms	1 watt	10%
R32	180	ohms	1 watt	10%
R41	27K	ohms	1 watt	10%
R42	270	ohms	1/2 watt	5%
R43	25K	ohms	10 watt	W/W
R44	1000	ohms	1/2 watt	5%
R45	5, 8	ohms	1 watt	5%
R51	2500	ohms	10 watt	W/W
R52	470K	ohms	1/2 watt	10%
R53	1 meg	ohms	1/2 watt	10%
R54	47K	ohms	2 watt	10%
R55	1000	ohms	1 watt	10%
R56	470K	ohms	1/2 watt	10%
R57	270	ohms	1/2 watt	10%
R58	2200	ohms	1/2 watt	10%
R59	22K	ohms	1/2 watt	10%
R71	500K	ohms	potentiometer	
R72	500	ohms	1/2 watt	10%
R88	5, 8	ohms	1 watt	5%
R89	250K	ohms	2 watt	5%

C11A }
 C11B } NPO using diskman. Part #388-5
 C11C }

C12	33mmf.	NPO 2-1/2% tubular ceramic	
C13	15mmf.	variable. Part #CT10075	
C14	33mmf.	NPO 2-1/2% tubular ceramic	
C15	15mmf.	variable. Part #CT10085	
C16	15mmf.	NPO 2-1/2% tubular ceramic	
C17	.001mmf.	500 volt mica	
C18	.005mmf.	disc ceramic	
C19	.005mmf.	disc ceramic	
C20	.01 mmf.	disc ceramic	
C21	100mmf.	NPO 10% tubular ceramic	
C22	.005mmf.	disc ceramic	
C23	.005mmf.	disc ceramic	
C24	.005mmf.	disc ceramic	
C25	1.5mmf.	tubular ceramic	10%

C31	100mmf.	disc ceramic	
C32A			
C32B	Dual 20mmf.	variable.	Part #186-2
C33	.005mfd.	disc ceramic	
C34	.005mfd.	disc ceramic	
C35	.01 mfd.	disc ceramic	
C36	.01 mfd.	disc ceramic	
C41	100mmf.	silver mica	
C42	.005mfd.	disc ceramic	
C43	.005mfd.	disc ceramic	
C44	.005mfd.	1500 volt disc ceramic	
C45	.005mfd.	disc ceramic	
C46	.0047mfd.	1500 volt disc ceramic	
C47	.005mfd.	1500 volt disc ceramic	
C48A			
C48B	Dual 140mmf.	variable.	Part #MCO13A
C49A			
C49B	Dual 40mmf.	variable.	Part #195-1
C50	.1 mfd.	400 volt tubular paper	
C52	.005mfd.	disc ceramic	
C53	.005mfd.	disc ceramic	
C54	.005mfd.	disc ceramic	
C55	.001mfd.	disc ceramic	
C56	.005mfd.	disc ceramic	
C57	.10 mfd.	disc ceramic	
C58	.10 mfd.	disc ceramic	
C60	8 mfd.	450 volt electrolytic	
C62	.005mfd.	disc ceramic	
C63	250mmf.	tubular ceramic	
C64	10 mfd.	50 volt electrolytic	
C66	.002mfd.	disc ceramic	
C68	.10 mfd.	450 volt tubular	
C69	.005mfd.	disc ceramic	
C71	250mmf.	GP tubular ceramic	
C72	10 mfd.	50 volt electrolytic	
L31	Oscillator	coil	Part #179
L32	Oscillator	coil	Part #180
L33	Oscillator	coil	Part #234
L44	2-1/2MH.	RF Choke	(125 ma.)
L45	Oscillator	plate coil	Part #240
L46	Oscillator	plate coil	Part #241
L47	Buffer plate	coil	Part #242
L48	Buffer plate	coil	Part #243
L49	Buffer plate	coil	Part #244
L50	Buffer plate	coil	Part #245
L51	Driver plate	coil	Part #246
L52	Driver plate	coil	Part #247
L53	Driver plate	coil	Part #248
L54	Driver plate	coil	Part #249
L55	Driver plate	coil	Part #250
L56	Driver plate	coil	Part #251
L57	Driver plate	coil	Part #252
L58	Driver plate	coil	Part #253
L59	Driver plate	coil	Part #254
L60	Driver plate	coil	Part #255
L61	2-1/2 MH.	RF Choke	(125 ma.)
L62	.4T	Microhenry	RF Choke
L63	2-1/2 MH.	RF Choke	(125 ma.)
L64	2-1/2 MH.	RF Choke	(125 ma.)
L65	80	meter plate	coil
L66	40 & 20	meter plate	coil

L-9T	15 & 10 meter plate coil	Part #185
L-48	5 meter plate coil	Part #856
T1	Class AB2 driver transformer	Part #121A3
T2	Modulation transformer	Part #121A8
SW11A	VFO section of bandswitch	Part #625
SW11B		
SW11C		
SW11D		
SW12A	VFO-CRYSTAL selector switch	Part #176
SW12B		
SW12C		
SW21	Buffer driver bandswitch	Part #624
SW31		
SW41A	Final plate bandswitch	Part #627
SW41B		
SW41C		
SW42A	Meter switch and final on-off switch	Part #175
SW42B		
SW42C		
SW51A	AM-CW switch	Part #631
SW51B		
SW51	VFO spotting switch	S. F. S. T. Toggle switch
SW52	Power on-off switch	S. F. S. T. Toggle switch
SW51	Carbon-deposit microphone switch	S. F. S. T. slide switch
B1	22-1/2 volt "90" battery	Bargess #116
PL1	544 pilot bulbs (Do not use any other number)	
PL2		
PL3	504 switchboard type pilot bulb (Sylvania)	
M	0 to 1 milliamperes meter	
V1	6AG6 Oscillator tube	
V2	6AQ5 Buffer-multiplier tube	
V3	6AQ5 R. F. driver tube (use Tung-Sol 6AQ5 tube only for best results)	
V4	6146 R. F. final amplifier tube	
V5	082 Voltage Regulator Tube	
V6	6AC6 Speech amplifier tube	
V7	12AU7 A. F. driver tube	
V8	6146D Modulator tube	
V9	6146D Modulator tube	
J1	Antenna Coax connector	Amphenol #3311
J2	Two conductor closed circuit jack	
J3	Three conductor open circuit jack	
Plastic dial enclosures	Part #543	
Cabinet	Part #543-C	
Front panel	Part #543	
Revol gears	Part #518	
Full handle (2)	Part #134	

4.2 RESISTOR GRAPH




CHART for determining the value of resistor "R" on drawing 4219, Figure 3, when using a single high voltage supply for the AF-68. The recommended wattage rating of this resistor is shown at the extreme left above. Be sure to use the actual voltage supplied by the power supply under load when using the chart above.

DRWG. NO. 663

4.3 OPERATING VOLTAGE CHART.

PIN NO.	1	2	3	4	5	6	7	8	9
TUBE NO.									
V2 Buffer 6AG5	-4*	1.5	zero (12.5V ^{ac})	6.3 ^{ac}	100	140	1.5	---	---
V3 Driver 6AQ5	-1*	6.7	6.3 ^{ac}	zero	225	200	zero	---	---
V4 Final 6J4E	1	zero (12.5V ^{ac})	Note 1	1	---	1	6.3 ^{ac}	zero	---
V5 Regulator 6X2	100	zero	---	zero	105	---	zero	---	---
V6 Speech 6AU6	zero	zero	6.3 ^{ac}	zero	25	40	1.2	---	---
V7 Audio Driver 12AU7	220	zero	1	zero	zero (12.5V ^{ac})	100	zero	1	6.3 ^{ac}
V8 Modulator 6L6CD	zero	zero (12.5V ^{ac})	Note 1	125	-22.5	---	6.3 ^{ac}	zero	---
V9 Modulator 6L6CD	zero	zero	Note 1	125	-22.5	---	6.3 ^{ac}	zero	---

This chart serves only as a guide, individual sets may vary from these readings.

All measurements made with a 20,000 ohms per volt voltmeter, using a 100V or 250V power supply or equivalent. Bandwidth in the 80 meter position, 500 dual sec at 3.5 megacycles, audio gain control set at minimum, TPO-CRYSTAL switch set in the VFO position, meter switch set to the first "G" (plate all position, final grid biasing condenser reconnected for maximum grid current, and the AM-CW switch set in the AM position.

Note 1--These readings depend upon final plate supply voltage.

* These measurements taken with a 100,000 ohm, 1 watt carbon resistor on the end of the negative voltage probe.

** Either AC or DC. Numbers in brackets are in effect when connected for 12 volt operation.

THRESHOLD CURRENT FOR
AM OR FM OPERATION

WAVE
AND THREE SCALING
ON WAVEFORM
OR IN FREQUENCY
OR IN POWER S.C.

V.F.O. - INTERNAL FREQUENCY
THE RANGE WITH WHICH THE UNIT IS
OPERATED FROM THE BUILT-IN V.F.O. OR
FROM AN EXTERNAL FREQUENCY INTO
THE POWER FROM THE UNIT.

WAVE SWITCH
IN POSITION:
FOR AM MODE THAT CURRENT WITH
PEAK VALUE 100% - 100% IS ON IN
ALL OTHER MODES SWITCH POSITIONED
TWO ON MODE THAT CURRENT WITH
THE PEAK VALUE 100%
TWO ON MODE THAT CURRENT WITH
THE PEAK VALUE 100%
TWO ON MODE THAT CURRENT WITH
THE PEAK VALUE 100%
TWO ON MODE THAT CURRENT WITH
THE PEAK VALUE 100%

V.F.O. SPOTTING SWITCH
WHEN THE SWITCH IS IN THE "ON" POSITION
THE SWITCH IS IN THE "ON" POSITION
THE SWITCH IS IN THE "ON" POSITION
THE SWITCH IS IN THE "ON" POSITION
THE SWITCH IS IN THE "ON" POSITION
THE SWITCH IS IN THE "ON" POSITION
THE SWITCH IS IN THE "ON" POSITION
THE SWITCH IS IN THE "ON" POSITION


V.F.O. CONTROL
A FREQUENCY CONTROL THAT PROVIDES
THE FREQUENCY OF OPERATION DIRECTLY IN
FREQUENCY

STEP
3

STEP
4, 7, 8

STEP
4B

STEP
4A




RECEIVING AREA
ALSO CARRY THE FREQUENCY OF THE
WAVE AND A FREQUENCY OF THE WAVE
WAVE THE WAVE OF THE WAVE

KEY AREA
HAS A TWO CURRENT
WAVE OF THE WAVE

OPERATING INSTRUCTIONS


1. WITH THE SWITCHES AND ALIGHT ABOUT TWO MINUTES AFTER THE
2. SELECT THE WAVE WITH THE SWITCHES
3. SELECT THE TYPE OF OPERATION DESIRED, AM OR FM, OR V.F.O. FOR THE
4. SELECT THE TYPE OF OPERATION DESIRED, AM OR FM.
5. SET THE V.F.O. TO THE FREQUENCY OF THE WAVE.
6. SET THE V.F.O. SPOTTING SWITCH TO THE "ON" POSITION AND TURN THE V.F.O. DIAL
UNTIL THE WAVE IS IN THE CENTER OF THE TUNING SCALE. TO DO THIS
WAVE THE V.F.O. SPOTTING SWITCH TO THE "ON" POSITION.
7. SET THE WAVE SWITCH TO THE "ON" POSITION.
8. TURN THE FREQUENCY DIAL UNTIL THE WAVE IS IN THE CENTER OF THE TUNING SCALE
AND THE WAVE IS IN THE CENTER OF THE TUNING SCALE.
9. SET THE WAVE SWITCH TO THE "ON" POSITION AND TURN THE FREQUENCY DIAL
UNTIL THE WAVE IS IN THE CENTER OF THE TUNING SCALE.
10. SET THE WAVE SWITCH TO THE "ON" POSITION AND CHECK THE WAVEFORM CURRENT OF THE
WAVE. THE WAVEFORM CURRENT OF THE WAVE IS IN THE CENTER OF THE TUNING SCALE
AND THE WAVE IS IN THE CENTER OF THE TUNING SCALE.




4.4 CONTROL LAYOUT

MULTI-PRODUCTS CO.			
2000 1000 1000 1000			
OPERATING INSTRUCTIONS			
MODEL	DATE	REVISION	REV.
AP-88	3-20-80	1000	854
REV.	REV.	REV.	REV.


4.1 CHASSIS LAYOUT



AFGQ COMPONENT LAYOUT
CNG 855



4-5-TYPE POWER PLUG CONNECTIONS




RF-6T
RF-6B PLUG CONNECTION

FIG. 1




Standard plug connection



RF-6T
RF-6B PLUG CONNECTION


FIG. 2

Standard plug connection




TOTAL 4-5 type plug connection

FIG. 3




AC grounded receptacle and standard plug connection

FIG. 4





AC grounded receptacle and standard plug connection

FIG. 5



4.7 SCHEMATIC WIRING DIAGRAM





OWNERS WARRANTY

All equipment manufactured by the Multi-Products Co. has been thoroughly tested and shipped from the factory in proper operating condition. This equipment is guaranteed to be free from any defects in workmanship and/or material for a period of 90 (ninety) days from date of original purchase as follows: Any part or accessory except tubes, crystals, microphones, and other trade articles not of our manufacture, shall be replaced free of charge providing the defect is in our opinion due to faulty workmanship and/or material, and not caused by tampering, abuse or normal wear. Tubes, crystals, microphones and other trade articles not of our manufacture are generally guaranteed by their respective manufacturers. The Multi-Products Co. will act as agent of these manufacturers in replacing such parts provided that such parts are returned to us pre-paid within a period of 90 (ninety) days from date of original purchase by the owner. The replacement of such parts will be in accordance with the warranty of the respective manufacturers. No further guarantee or warranty is implied. In accepting delivery, the purchaser assumes full responsibility for proper installation and service arrangements.

This warranty is valid only if the Owner's Registration Card has been filled out by the purchaser and mailed to The Multi-Products Co. at the time of original purchase.


This warranty is void if the equipment has been modified or if failure is due to the application of voltages other than those specified in this manual.

Do not return any equipment or accessory direct to the factory without first obtaining authorization from the factory. All equipment to be returned shall be shipped pre-paid and insured by the owner.

Any claims for damage or loss in transit must be filed with the carrier. The Multi-Products Co. will give any necessary assistance in filing such claims.

The Multi-Products Co. reserves the right to make changes in current production models without being obligated to incorporate such changes in earlier production models.

Multi-Products Co.



www.everything4lessstore.com